SUMMARY OF NCHRP RESEARCH ON DEVELOPMENT OF A PRECAST BENT CAP SYSTEM FOR SEISMIC REGIONS

Waseem Dekelbab¹

Abstract

This paper summarizes the findings of the research conducted under NCHRP Project 12-74 to (1) develop and validate design methodologies; (2) recommend design and construction specifications; and (3) provide design examples and example connection details for precast bent cap systems using emulative and hybrid connections for integral and nonintegral systems for all seismic regions throughout the United States.

Introduction

Precast bent cap systems are of increasing utility in highway construction. Precasting eliminates on-site concrete forming, placement, and curing operations making bridge construction safer and more environmentally friendly. It also removes bent cap construction from the critical path, thus accelerating the construction process. Precasting also improves quality and durability because the work is performed in a controlled environment. These benefits of precast bent cap systems support the philosophy of "get in, get out, stay out." Successful use of precast bent caps relies on proper design, constructability, and performance of the connections. Early uses of precast bent caps were limited to applications where minimal moment and shear transfer were required at connections. In seismic regions, provisions normally must be made to transfer greater forces through connections and to ensure girder continuity in the longitudinal direction.

Precast bent cap systems can be classified as either integral or nonintegral depending on superstructure-to-substructure connectivity. Integral bent cap systems develop longitudinal continuity through girder-to-bent cap connections. In contrast, nonintegral bent cap systems use bent cap-to-column connections to provide transverse moment continuity. However, integral precast bent cap systems require the use of precast cap-to-column and superstructure-to-cap connections.

Additionally, precast connections are typically categorized as being either emulative or hybrid. Emulative connections are designed to produce a system performance that is similar to (or "emulates") that achieved by traditional monolithic, cast-in-place (CIP) construction. Bridges using emulative precast bent cap connections are expected to form plastic hinges in the columns and redistribute forces to other members like CIP systems. The lateral force-displacement response of an emulative system is characterized by full hysteresis loops and stable energy dissipation. This

¹ Senior Program Officer, National Cooperative Highway Research Program, TRB, Washington, DC

response results from considerable damage and potential residual deformations--the underlying assumption of seismic design philosophy for CIP bridges. Hybrid systems are designed to provide sufficient energy dissipation through controlled rocking about specially detailed joints at the column ends. In addition, hybrid systems provide a significant reduction in damage and residual offsets as compared to cast-in-place and emulative systems.

NCHRP Project 12-74 was conducted to (1) develop and validate design methodologies, (2) recommend design and construction specifications, and (3) provide design examples and example connection details for precast bent cap systems using emulative and hybrid connections for integral and nonintegral systems for all seismic regions throughout the United States.

In this paper, the research efforts conducted under this NCHRP project related to nonintegral systems are summarized. The efforts summarized herein are: (1) experimental test program; (2) testing protocol and instrumentation; and (3) test results and key findings, extracted from the project's final report authored by the principal investigator Dr. Jose I. Restrepo, professor at University of California, San Diego (UCSD); and the co-principal investigator Dr. Eric E. Matsumoto, professor at California State University, Sacramento (CSUS).

Experimental Test Program

In this research program, a number of promising precast bent cap details were investigated though experimental testing. These specimens were developed to meet a variety of performance objectives for locations throughout the nation's seismic regions; descriptions are provided in Table 1.

		<i>J</i> 1	1
Code	Specimen Name	Specimen Type	Specimen Purpose
CIP	Cast-in-place control specimen	Beam-to-column emulative	Control specimen detailed in accordance with Recommended AASHTO LRFD Seismic Guide Specification for high seismic applications.
GD	Grouted duct specimen	Beam-to-column emulative	Grouted duct specimen designed to provide high ductility response with similar response as CIP specimen

Table 1 Summary of Experimental Specimens

Code	Specimen Name	Specimen Type	Specimen Purpose
CPFD	Cap pocket full ductility specimen	Beam-to-column emulative	Cap pocket specimen designed to provide high ductility response with similar response as CIP specimen. Detail uses a corrugated metal pipe to provide stay-in-place form and joint shear reinforcement
CPLD	Cap pocket limited ductility specimen	Beam-to-column emulative	Cap pocket specimen design with alleviated seismic detailing intended to provide limited ductility for regions of low to moderate seismicity. Detail uses similar corrugated metal pipe detail as CPFD.
Hybrid 1	Conventional hybrid specimen	Beam-to-column hybrid	Hybrid specimen detailed with conventional spiral confinement reinforcement and full length mild reinforcement. Detail is intended to be a hybrid detail most similar to traditional CIP construction.
Hybrid 2	Concrete filled pipe hybrid specimen	Beam-to-column hybrid	Hybrid specimen using full length steel shell acting as confinement and shear reinforcement. Mild reinforcement utilized only at joint to provide energy dissipation and terminated into the column.
Hybrid 3	Dual steel shell hybrid specimen	Beam-to-column hybrid	Hybrid specimen using two full length shells (outer steel and inner corrugated metal pipe) acting as confinement and shear reinforcement. Mild reinforcement utilized only at joint. Dual shell detail intended to reduce weight of column section for precasting.

Testing Protocol and Instrumentation

In the following sections, the test setup, loading, and instrumentations for nonintegral emulative and hybrid specimens will be summarized.

Emulative Specimens

The specimen test setup, shown in Figure 1, included a simply supported bent cap with a column stub that allowed biaxial loading and accurate establishment of specimen forces. The specimen was tested in inverted position. Loads were applied using a vertical hydraulic actuator to apply scaled gravity load and the horizontal hydraulic actuator to induce seismic response. The test setup ensured accurate conditions at each end of the joint so that the force transfer mechanism in the joint could be investigated. Different axial force conditions in the bent cap were produced for the push and pull directions.

Force controlled and displacement controlled loadings were applied to all specimens. The force controlled loading was used for an approximate determination of first yield of column longitudinal bars in the push and pull directions, establishment of effective yield, and application of the displacement controlled sequence including quasistatic displacement in 3 cycles. Nominal displacement ductility (μ) demand, as multiples of system effective yield displacement, was applied at the μ 1, μ 1.5, μ 2, μ 3, μ 4, μ 6, μ 8, and μ 10 levels, or until the residual capacity of the specimen dropped below 30% of the maximum load.

External gages, including linear and string potentiometers and Linear Variable Differential Transformers (LVDT) were mounted on the column, joint, and bent cap. Internal strain gages were placed on bent cap, joint, and column reinforcing bars, as well as corrugated ducts or pipe. In addition to the approximately 100 sets of data, specimen response was also monitored using digital photos, crack markings and measurements, video recording, and notes.

Hybrid Specimens

The test setup for the hybrid specimens, shown in Figure 2, is similar to that used for the emulative specimens. The specimens were constructed in the upright condition and then inverted for installation in the test setup. The vertical actuator was set to apply a constant load during testing to simulate gravity loading. This force varied between hybrid specimens in order to match the lateral response of the three hybrid tests. The horizontal actuator was actively controlled to apply specified forces or displacements during testing.

The initial stage of loading consisted of force-controlled loading protocols in which positive and negative lateral forces of increasing magnitude were applied until first yield of the extreme mild reinforcing bar was reached. Each force loading cycle was repeated three times in both directions. Following the first yield of the system, the lateral loading was applied to a specified lateral drift ratio. At each cycle to a given drift ratio, the column was subjected to two cycles in both directions followed by one cycle to the previous lateral drift. This protocol was developed to help accurately calibrate non-linear models of the system.

External instrumentation mounted on the specimens consisted of linear potentiometers and inclinometers for measuring and isolating various modes of deformation in the member. In addition, a significant number of internal strain gages were employed to capture the local response of materials.



Figure 1 Test Setup for Emulative Specimens



Figure 2 Test Setup for Hybrid Specimens

Test Results and Key Findings

This section summarizes the key aspects of specimen response for the emulative and hybrid experimental tests. In reporting specimen response, displacement ductility, μ , and drift ratio are both used. Drift ratio is defined as the column displacement divided by the column height, and is reported as a percent. It provides a more consistent basis for comparison of specimen response than displacement ductility. However, system ductility levels are also reported, although these values should be considered nominal (i.e., approximate) due to the approximate determination of first yield. The terms drift and drift ratio are used interchangeably.

Non-integral Emulative Connections

This section summarizes the primary aspects of specimen response for all specimens: Cast-in-Place (CIP), Grouted Duct (GD), Cap Pocket Full Ductility (CPFD), and Cap Pocket Limited Ductility (CPLD). The joint response is summarized in Tables 2 and 3. Comparisons are made between the CIP and precast connections, as well as between the full and limited ductility specimens. GD as well as CPFD joint distress was limited and joint behavior compared very favorably with that of the CIP specimen. In contrast, the joint region for the CPLD specimen exhibited a significant level of distress that increased throughout the test. Figure 3 shows the joint shear stress-strain response envelopes, and Figure 4 shows the load-displacement envelopes for all specimens. The figures reveal a very similar overall load-displacement response for the GD, CPFD, CPLD and CIP specimens. The dominance of ductile plastic hinging in the column and minimal damage in the capacity-protected joint and bent cap satisfied the performance goal for the GD emulative specimen.

Parameter		CIP	GD	CPFD	CPLD
Joint Shear Stress (p	psi)	328 (4.86 $\sqrt{f_c}$)	312 (4.62 $\sqrt{f_c}$)	323 (4.31 $\sqrt{f_c}$)	371 (6.32 $\sqrt{f_c}$)
Principal Tensile Stress (p	psi)	363 $(5.38\sqrt{f_c'})$	343 (5.09 $\sqrt{f_c}$)	356 (4.75 $\sqrt{f_c}$)	411 (6.99 $\sqrt{f_c'}$)
Principal Compressive (p Stress	psi)	401 (0.088 $f_c^{'}$)	370 (0.081 <i>f</i> _c ['])	398 (0.071 <i>f</i> _c ['])	460 $(0.13f_c')$
Angle of Principal Plane (d	leg)	45.0	45.0	44.2	44.8
Joint Rotation (r	ad)	1.95 x 10 ⁻³	2.25 x 10 ⁻³	1.73 x 10 ⁻³	2.87 x 10 ⁻³
Change in Panel (⁴ Area	%)	0.16	0.19	0.13	0.46

Table 2 Maximum Joint Response

Table 3 Maximum	Joint Response –	Comparison Ratios
1 4010 0 1124	• • • • • • • • • • • • • • • • • • •	

Parameter	GD/CIP	CPFD/CIP	CPLD/CIP	CPLD/CPFD
Joint Shear Stress	0.95	0.89	1.30	1.47
Principal Tensile Stress	0.94	0.88	1.30	1.47
Principal Compressive Stress	0.92	0.81	1.48	1.86
Angle of Principal Plane	1.00	0.98	1.00	1.01
Joint Rotation	1.15	0.89	1.47	1.66
Change in Panel Area	1.19	0.81	2.82	3.26



Figure 3 Joint Shear Stress vs. Joint Shear Strain Envelopes





Non-integral Hybrid Connections

This section summarizes the primary aspects of specimen response including column hysteretic response (lateral force-displacement), joint response, and residual drift. Comparisons are made between the CIP and hybrid connections (Hybrid 1—conventional hybrid specimen, Hybrid 2—concrete filled pipe hybrid specimen, and Hybrid 3—dual steel shell hybrid specimen). The force-displacement envelopes for all three hybrid specimens along with the cast-in-place specimen are shown in Figure 5. It is apparent that all hybrid specimens have greater lateral capacity than the cast-in-place control. The higher lateral capacity resulted from the larger than anticipated effective post-tensioning force in the conventional hybrid specimen. Regarding joint response, only minor damage occurred within the joint during the entire testing of all hybrid specimens. Diagonal cracking patterns were observed indicating joint shear cracking, but the joint reinforcement was adequate to resist extensive crack growth and subsequent joint damage.

One of the major aims of hybrid bridge systems is the reduction of residual displacements. Figure 6 shows the ratio of recorded residual drift to the maximum drift during the first cycle for the three hybrid and the cast-in-place control specimens. However, the second cycle exhibited slightly greater residual drifts. In general, for the conventional hybrid specimen the residual drift ratio increases with the applied lateral drift. However, the recorded residual drift was significantly less than for the cast-in-place specimen indicating an expected improved post-earthquake performance.



Figure 5 Lateral Force vs. Lateral Displacement Envelopes for Hybrid Connections



Figure 6 Residual Drift Ratio vs. Applied Drift Ratio for Hybrid Connections

Key Findings

Based on a review of the experimental efforts conducted under NCHRP 12-74, the research team provided the following key findings:

• The current joint shear design methodology contained in the 2009 LRFD Seismic Guide Specification, with minor modifications, is appropriate for the design of emulative and hybrid, integral and nonintegral precast bent cap systems.

• For Seismic Design Categories (SDCs) B, C and D, the level of joint shear reinforcement should be based on the calculated principal tensile stress, and if the stress exceeds $0.11\sqrt{f_c}$, ksi, joint shear reinforcement should be specifically designed.

• Minimum joint shear reinforcement should be provided for all SDCs.

• Design methodologies and detailing for hybrid systems should be employed to facilitate the implementation of these systems for improving the post-earthquake functionality of the bridge structure.

• Properly designed and detailed hybrid systems can produce substantially less residual deformation and damage than cast-in-place and emulative systems.

• In hybrid systems, the contribution of flexural reinforcement should be limited to produce its intended response. In addition, the neutral axis depth should be limited to minimize the magnitude of compressive strains within the section.

• Design and detailing of the unbonded post-tensioning and longitudinal reinforcement in a hybrid system should be such as to ensure premature fracture does not occur.

• Provisions of the 2009 LRFD Seismic Guide Specification for the design of multicolumn integral connections should be updated for consistency with the design of multicolumn nonintegral connections.

• For the cap pocket connections, the use of a supplementary hoop at the top and bottom of the corrugated pipe should be employed.

• Proposed equations for anchorage of reinforcement within grouted ducts and the cap pocket connection should be implemented.

• Future provisions of seismic design and detailing requirements should be developed for knee joints for both cast-in-place and precast bent caps.

• Alternate connection details are provided for structures located in SDC A with S_{DI} less than 0.10. However, minimum vertical stirrups in the joint are recommended, as well as the extension of column longitudinal reinforcement as close as practical to the top of the bent cap.

• Grouted joints for use in seismic applications should be limited to 3 inches in thickness and should be reinforced with hoops to maintain the spacing of lateral reinforcement within the plastic hinge region.

• For hybrid columns and integral closure joints, grouted connections should employ a 3 pound per cubic yard fraction of polypropylene fibers to enhance the integrity of the joint.

Conclusions

In addition to the contractors' final report that will be published as NCHRP Report 681, Development of A Precast Bent Cap System for Seismic Regions, a series of recommended updates to the AASHTO LRFD Bridge Design Specifications, Guide Specification for LRFD Seismic Bridge Design and Bridge Construction Specifications were developed.

Design specifications SDCs C and D, SDC B, and SDC A were developed in appropriate format for incorporation into a future edition of the *AASHTO Guide Specifications for LRFD Seismic Bridge Design* (LRFD SGS). A major proposed change is to revise Article 8.13—Joint Design for SDCs C and D of the 2009 LRFD SGS to include precast bent cap connections (grouted duct and cap pocket). Also, to address all seismic design categories, two new articles were required and recommended to be added: an article on Joint Design for SDC A and an article on Joint Design for SDC B.

Design flow charts and design examples were developed to illustrate the use of design specifications for both grouted duct and cap pocket connections at all SDC levels. Construction specifications, Special Requirements for Precast Bent Cap Connections, were provided and proposed for inclusion in the AASHTO LRFD Bridge Construction Specifications (LRFD BCS).

Acknowledgements

The work summarized herein was performed under NCHRP Project 12-74 and was guided by NCHRP Project Panel C12-74, chaired by Mr. Richard A. Pratt, with members Dr. Xiaohua Hannah Cheng, Mr. Carl J. Fuselier, Mr. Jim Ma, Mr. Richard Marchione, Mr. Chuck Prussack, Ms. Holly Winston, and Mr. Lloyd M. Wolf. Mr. Derrell A. Manceaux and Mr. Stephen F. Maher provided liaison with the FHWA and TRB, respectively. Dr. Waseem Dekelbab served as the responsible NCHRP staff officer. The final report was prepared by the principal investigator Dr. Jose I. Restrepo, professor of structural engineering at the University of California, San Diego (UCSD), and the coprincipal investigator Dr. Eric E. Matsumoto, Professor at California State University, Sacramento (CSUS). The other author of this report is Dr. Matthew J. Tobolski, President of Tobolski Watkins Engineering, Inc. and former graduate researcher at UCSD.

	APPROXIM	ATE CONVERSION	S TO SI UNITS	
Symbol	When You Know	Multiply By	To Find	Symbol
		LENGTH		
in	inches	25.4	millimeters	mm
ft	feet	0.305	meters	m
yd	yards	0.914	kilomotors	iii km
	mies		RIOTIELEIS	NIII
im ²	aquara inabaa	AREA	aquero millimotoro	2
ff ²	square incries	0/15.2	square minimeters	m ²
n. wd ²	square yard	0.095	square meters	m ²
ac	acres	0.000	hertares	ha
mi²	square miles	2.59	square kilometers	km ²
	- ,	VOLUME		
fl oz	fluid ounces	29.57	milliliters	mL
gal	gallons	3.705	liters	L
ft ³	cubic feet	0.028	cubic meters	m³
yd³	cubic yards	0.765	cubic meters	m³
	NOTE: volu	imes greater than 1000 L sha MASS	II be shown in m ³	
0Z	ounces	28.35	grams	a
lb	pounds	0.454	kilograms	kg
т	short tons (2000 lb)	0.907	megagrams (or "metric ton")	Mg (or "t")
	TE	MPERATURE (exact d	egrees)	
°F	Fahrenheit	5 (F-32)/9 or (F-32)/1 8	Celsius	°C
		ILLUMINATION		
			here:	ly:
fc	foot-candles	10.76	IUX	14
fc fl	foot-candles foot-Lamberts	10.76 3.426	candela/m ²	cd/m ²
fc fl	foot-candles foot-Lamberts	10.76 3.426 CE and PRESSURE or	candela/m ²	cd/m ²
fc fl	foot-candles foot-Lamberts FOR poundforce	10.76 3.426 CE and PRESSURE or 4.45	candela/m ² STRESS newtons	cd/m ²
fc fl Ibf Ibf/in ²	foot-candles foot-Lamberts FOR poundforce poundforce per square inch	10.76 3.426 CE and PRESSURE or 4.45 6.89	candela/m ² STRESS newtons kilopascals	cd/m ² N kPa
fc fl Ibf Ibf/in ²	foot-candles foot-Lamberts poundforce poundforce per square inch APPROXIMA	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS	candela/m ² STRESS newtons kilopascals FROM SI UNITS	cd/m² N kPa
fc fl lbf lbf/in ² Symbol	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By	STRESS newtons kilopascals FROM SI UNITS To Find	N kPa Symbol
fc fl lbf lbf/in ² Symbol	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH	STRESS newtons kilopascals FROM SI UNITS To Find	N kPa Symbol
fc fl Ibf Ibf/in ² Symbol	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039	STRESS newtons kilopascals FROM SI UNITS To Find inches	N kPa Symbol
fc fl Ibf Ibf/in ² Symbol mm m	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28	STRESS newtons kilopascals FROM SI UNITS To Find inches feet	N kPa Symbol
fc fl Ibf Ibf/in ² Symbol mm m m	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards	N kPa Symbol in ft yd
fc fl Ibf Ibf/in ² Symbol mm m m km	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles	N kPa Symbol in ft yd mi
fc fl Ibf/in ² Symbol mm m km	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles	N kPa Symbol in ft yd mi
fc fl Ibf/in ² Symbol mm m km mm ²	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches	N kPa Symbol in ft yd mi
fc fl Ibf Ibf/in ² Symbol mm m km km	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet	N kPa Symbol in ft yd mi in ² ft ²
fc fl Ibf Ibf/in ² Symbol mm m km mm ² m ²	foot-candles foot-Lamberts FOR poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square yards	N kPa Symbol in ft yd mi in ² ft ² yd ²
fc fl Ibf/in ² Symbol mm m km m ² m ² m ² ha	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square yards acres	in ft yd mi in ² ft ² yd ² ac
fc fl Ibf/in ² Symbol mm m km m ² m ² m ² ha km ²	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters square meters hectares square kilometers	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square yards acres square miles.	in ft yd mi in ² ft ⁻ yd ² ac mi ²
fc fl Ibf/in ² Symbol mm m km m ² m ² ha km ²	foot-candles foot-Lamberts poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square kilometers	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square feet square miles	in ft yd mi in ² ft ² yd ² ac mi ²
fc fl Ibf/in ² Symbol mm m m km m ² m ² ha km ² mL	foot-candles foot-Lamberts Poundforce poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034	Itx candela/m ² STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square feet square miles fluid ounces	IN KPa Symbol in ft yd mi in ² tt ² yd ² ac mi ² fl oz
fc fl Ibf Ibf/in ² Symbol mm m km km ² ha km ² ha km ²	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square yards acres square miles	IN KPa Symbol in ft yd mi in ² ft ² yd ² ac mi ² fl oz gal
fc fl Ibf Ibf/in ² Symbol mm m m km m ² ha km ² km ² L L m ³	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares square meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 4.27	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square inches square feet square yards acres square miles. fluid ounces qallons cubic feet	IX Cd/m ² N kPa Symbol in ft yd mi in ² ft ² yd ² ac mi ² fl oz gal ft ³ ud ³
fc fl Ibf Ibf/in ² Symbol mm m m km m ² m ² ha km ² mL L m ³	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares cubic meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square yards acres square miles fluid ounces qallons cubic feet cubic yards	IX Cd/m ² N kPa Symbol in ft yd mi in ² ft ² yd ² ac mi ² fl oz qal ft ³ yd ³
fc fl Ibf Ibf/in ² Symbol mm m m km m ² m ² ha km ² mL L m ³ m ³	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares cubic meters cubic meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.25	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square yards acres square miles: fluid ounces qallons cubic feet cubic yards	IN KPa Symbol in ft yd mi in ² ft ² yd ² ac mi ² fl oz gal ft ³ yd ³
fc fl Ibf Ibf/in ² Symbol Symbol mm m km m ² m ² ha km ² km ² g g g	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square kilometers milliliters liters cubic meters cubic meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.302	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square yards acres square miles. fluid ounces qallons cubic feet cubic feet cubic yards	IN KPa Symbol in ft yd mi in ² ft ² yd ² ac mi ² fl oz gal ft ³ yd ³ OZ
fc fl Ibf Ibf/in ² Symbol Symbol mm m km m ² m ² ha km ² km ² km ² kg Mg (or "")	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares square meters hectares square meters duiters cubic meters cubic meters cubic meters grams kilograms	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.102	IXX candela/m ² STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square yards acres square miles fluid ounces qallons cubic feet cubic feet cubic feet cubic ret tane (2000 lb)	IN KPa Symbol in ft yd mi in ² ft ² yd ² ac mi ² fl oz qal ft ³ yd ³ oz lb T
fc fl Ibf/in ² Symbol mm mm ^m km m ² m ² ha km ² kg Mg (or "t")	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MDEP ATUPE (assort d	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square feet square miles fluid ounces qallons cubic feet cubic feet cubic feet cubic feet cubic sards	In ft yd mi ft yd mi ft ft ² ft ² yd ² ac mi ² fl oz qal ft yd ³ oz lb T
fc fl Ibf Ibf/in ² Symbol Mm mm mm km mm ² m ² ha km ² mL L m ³ m ³ g kg Mg (or "t")	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares cubic meters cubic meters cubic meters cubic meters cubic meters megagrams (or "metric ton")	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact d 1.8C+32	Itx candela/m ² STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square inches square feet square yards acres square onles fluid ounces qallons cubic feet cubic yards ounces pounds short tons (2000 lb) egrees) Fahrenheit	In ft yd mi ft ² yd ² ac mi ² fl oz gal ft ³ yd ³ oz lb T °F
fc fl Ibf Ibf/in ² Symbol Symbol mm m km m ² m ² ha km ² m km ² m km ² m ³ m ³ g kg Mg (or "t")	foot-candles foot-Lamberts poundforce poundforce per square inch APPROXIMA When You Know When You Know millimeters meters meters kilometers square millimeters square meters square meters square meters hectares square meters hectares cubic meters cubic meters cubic meters meters hectares square meters hectares square meters hectares square meters hectares square meters hectares cubic meters cubic meters meters hectares cubic meters cubic meters meters hectares cubic meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact d 1.8C+32 ILLUMINATION	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square yards acres square miles. fluid ounces qallons cubic feet cubic feet cubic feet cubic reet short tons (2000 lb) egrees) Fahrenheit	n kPa Symbol in ft yd mi in² ft ⁻ yd² ac mi² fl oz gal ft³ yd³ oz lb T °F
fc fl llbf llbf/in ² Symbol mm m km m ² m ² ha km ² m ² ha km ² m ³ g kg Mg (or "t") °C	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square kilometers milliliters liters cubic meters cubic meters cubic meters cubic meters cubic meters cubic meters cubic meters cubic meters megagrams (or "metric ton") Celsius	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact d 1.8C+32 ILLUMINATION 0.0929	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square yards acres square miles. fluid ounces qallons cubic feet cubic feet cubic reet cubic reet short tons (2000 lb) egrees) Fahrenheit foot-candles	N kPa Symbol in ft yd mi in ² ft ⁻ yd ² ac mi ² fl oz qal ft ³ yd ³ oz lb T °F
fc fl llbf llbf/in ² Symbol mm m km m ² m ² ha km ² mL L m ³ m ³ g kg Mg (or "t") °C	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters milliliters itters cubic meters cubic meters megagrams (or "metric ton") Celsius	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact d 1.8C+32 ILLUMINATION 0.0929 0.2919	STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square yeards acres square miles fluid ounces qallons cubic feet cubic feet cubic feet cubic ret cubic ret short tons (2000 lb) egrees) Fahrenheit foot-candles foot-Lamberts	n kPa Symbol in ft yd mi in² ft ⁻ yd² ac mi² fl oz qal ft³ yd³ oz lb T °F fc fl
fc fl llbf llbf/in ² Symbol mm m m km m ² m ² ha km ² m ² ha km ² m ² kg Mg (or "t") °C lx cd/m ²	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters the component of the component milliliters iters cubic meters cubic meters cubic meters for meters megagrams (or "metric ton") TE Celsius	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact d 1.8C+32 ILLUMINATION 0.0929 0.2919 CE and PRESSURE or	Itx candela/m ² STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square feet square miles fluid ounces qallons cubic feet cubic feet cubic feet cubic feet cubic feet cubic res short tons (2000 lb) egrees) Fahrenheit foot-candles foot-Lamberts STRESS	In ft yd mi in ft yd mi in îr ft' yd mi in² ft' yd² ac mi² fl oz gal ft' yd³ oz lb T oz lb T °F fc fl
fc fl llbf llbf/in ² Symbol mm mm km m ² m ⁴ km km ² mL L m ³ m ³ g kg (or "t") °C k cd/m ²	foot-candles foot-Lamberts FOR poundforce per square inch APPROXIMA When You Know millimeters meters meters kilometers square millimeters square meters square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares square meters hectares cubic meters cubic meters cubic meters cubic meters for meters cubic meters cubic meters for meters for meters megagrams (or "metric ton") for meters	10.76 3.426 CE and PRESSURE or 4.45 6.89 ATE CONVERSIONS Multiply By LENGTH 0.039 3.28 1.09 0.621 AREA 0.0016 10.764 1.195 2.47 0.386 VOLUME 0.034 0.264 35.314 1.307 MASS 0.035 2.202 1.103 MPERATURE (exact d 1.8C+32 ILLUMINATION 0.0929 0.2919 CE and PRESSURE or 0.225	Itx candela/m ² STRESS newtons kilopascals FROM SI UNITS To Find inches feet yards miles square inches square feet square feet square reet square miles fluid ounces qallons cubic feet cubic feet cubic feet cubic yards ounces pounds short tons (2000 lb) egrees) Fahrenheit foot-candles foot-Lamberts STRESS poundforce	Ccd/m ² N kPa Symbol in ft yd mi in ² ft ⁻ yd ² ac mi ² fl oz qal ft ² yd ³ oz lb T °F fc fl lbf